



Calibrate TCM

- HillMaster up (If equipped)
- Tyre pressures even
- Flat surface-Ideally concrete yard
- Do it accurately use reference point– Two people!
- If machine is on tracks use track idler for reference point